




Auto Compact Air Inflator

Problem





Features



- •Size 234x57x45mm, small enough to fit in your pocket or backpack.
- •Fast inflation, flat tyre or ball
- Single button operation
- •Up to 150PSI = 10.3Bar
- Rechargeable, no battery is needed







Small & Smart



LED Display



Ultra High Pressure



LED Light







Item NO

TYREIO



Size	234*57*45(mm)	
Weight	430g	
Battery	2600mAh 7.4V	
Work current	1-6A	
Charging mode	Type_c	
Charging time	2 hours	
Max inflating pressure	150PSI & 10.3BAR	
Operation temperature	-10°C ~ +60°C	
















	Reference pressure	Time from empty	Frequency from empty
Car	2.3-2.5bar	8–12min	2–3 (205 55R17)
Road Bike	100-120psi	2–3min	8-12 (700*23C)
Mountain Bike	30-50psi	2–3min	12–18 (26*1.95)
Motorcycle	30-50psi	2–3min	8–12
Basketball	7-9psi	0.5–1min	30–40

Inflatable Interface			
Valve Type	American valve	French	Ball














- 1 Inflator
- 2 Air Tube
- 3 Type_C Charging Cable
- 4 Valve Converter
- 6 Ball Converter

Details







Using Instruction

- 01. Long press the POWER Button to turn on the power. The LED will display the current pressure.
- 02. Long press the UNIT button can switch the units PSI and BAR. If short press, you can switch between 5 modes of use: custom, car, motorcycle, bicycle, and basketball. Commonly used air pressure values are preset in each mode.




- 03. The + Button and Button are used to adjust the preset air pressure value, long press them can quickly adjust. (In the custom mode, A7 will memorize the pressure value last set)
- 04. Pressing the POWER Button can start inflating. Pressing it again can pause/ continue. It will stop automatically when it reaches the target pressure.



About Charging

- 01. For the first time to use or a long time no use, please charge the inflator before using.
- 02. The charging indicator will turn red during the charging and turn green when the battery is fully charged.
- 03. Usually, the air inflator should be charged every two months even though it was not used. if you do not charge it for a long time, the battery will be over-discharged and lead to battery damaged.



omotic

Attention

01. It's normal that the inflator becomes hot after working more than 1 min. Please don't touch the hot part of the air tube!



- Please check the inflator before inflating.
 If find any exception, don't use it.
- 03. If find any abnormal sounds or excessive temperatures during the inflation, please stop using it immediately.
- Please ensure the smooth flow of air during the inflation.
- 05. The compressor in the inflator may produce electric sparks at work. Please keep it away from flammable and explosive objects.
- Don't leave to prevent accidents during inflating.
- 07. After long-time using, both the inflator and the air tube will become hot. Please take a break before using it again.

- Please try to avoid silt invasion, soaking and bad fall.
- Harsh chemicals, cleaning agents, detergents and other chemicals are forbidden to be used during the cleaning.
- Don't store the inflator in a cold, hot and humid place.
- Children are forbidden to use the inflator.
 Please keep it away from children.
- Don't inflate the air into the mouth, ear, eye, etc. of the persons or animals.
- Inflating is not recommended during the charging.
- 14. When the inflator is working, because the electric current is large, the battery power is low, only for reference.



THANK YOU